



- Dispose of used fasteners (1).
- Only use new fasteners (2).
- Do **not** use impact wrench (3).
- Tighten fasteners to the specified tightening torque (4).
Observe the vehicle manufacturer specifications.
- Measure wheel alignment (5, 6).
Observe the vehicle manufacturer specifications.

