



Fig. 1: Release bearing with nutating balance

- 1 Clutch release bearing
- 2 Thrust ring with nutating balance



The clutch release bearing (1) is equipped with a mechanism to balance nutation (Fig. 1). The nutating balance mechanism compensates for tolerances in the driveline. The thrust ring with nutating balance (2) is designed in such a way that it can easily be moved by hand. This is not a fault; the clutch release bearing can be installed.



www.zf.com/serviceinformation