



MERCEDES-BENZ S-KLASSE (W221), S-KLASSE Coupe (C216)



WARNING

Health risk!

Inhalation of brake dusts may result in serious damage to the respiratory organs!

Do not clean brake components with compressed air.


Use brake cleaner fluid.

General reference notes

The control unit with the parking brake servomotor is located on the underbody.

The parking brake switch is located in the dashboard. **(1)**
(see figure 1)

Figure 1



1 Parking brake switch

Display/operation

Automatic mode

Bonnet closed.

Seat belt fastened.

The parking brake releases automatically as soon as the vehicle is being driven in the 1st gear or when reversing.

Engage parking brake

Pull parking brake switch.

Disengage parking brake

Press parking brake switch backward.


The yellow indicator light goes on when errors occur that impair operating or traffic safety. **(2)**

Read off error code on display.

(see figure 2)

For further details and information, please refer to the operating manual!

Figure 2



1 Indicator light

2 Fault indicator light

3 Instrument cluster display